



# Data Sheet

## Keyboard encoder IC 9600-PRO

**RS stock number 633-161**

The 9600 is a keyboard encoder that contains all the logic necessary to debounce and encode the SPST key switches used in a keyboard matrix and provide a fully decoded data output consisting of a nine bit simple binary code which can be converted to the required information code by a PROM or microprocessor etc. This permits maximum user flexibility for key layout and coding.

Contact bounce elimination circuitry with an externally controllable delay is included and data outputs are TTL compatible.


### Absolute maximum ratings

Positive voltage any pin with respect to Gnd \_\_\_\_ +8.0V  
 Negative voltage any pin with respect to Gnd \_\_\_\_ 0.3V  
 Operating temperature range \_\_\_\_\_ 0°C to +70°C  
 Storage temperature range \_\_\_\_\_ -55°C to +150°C  
 Lead temperature soldering 10s \_\_\_\_\_ +325°C

### Features

- On-chip contact bounce elimination
- N-Key rollover or lockout operation
- TTL compatible data outputs
- Normal, shift, control and shift-control modes
- Simple binary code output for user conversion
- Single + 5V supply.

### Pin connections




Top view

Electrical characteristics TA = 0°C to 70°C, V<sub>CC</sub> = 5V ±5%

| Parameter                    | Conditions                    | Min. | Typ. | Max. | Units |
|------------------------------|-------------------------------|------|------|------|-------|
| <b>dc characteristics</b>    |                               |      |      |      |       |
| Low level input voltage      |                               |      |      | 0.8  | V     |
| High level input voltage     | Except Y inputs               | 2.0  |      |      | V     |
| Y input high level           |                               | 2.8  |      |      | V     |
| Y input low level            |                               |      |      | 0.8  | V     |
| Input leakage current        | Except Y V <sub>IN</sub> = 5V |      |      | 10.0 | µA    |
| Input with pull down R       | V <sub>IN</sub> = 5V          | 75   | -400 | 220  | µA    |
| Y inputs                     | V <sub>YIL</sub> = 1V         | -100 |      | -500 | µA    |
| <b>Output voltage levels</b> |                               |      |      |      |       |
| Low level                    | I <sub>OL</sub> = 1.6mA       |      |      | 0.4  | V     |
| High level                   | I <sub>OH</sub> = 100µA       | 2.4  |      |      | V     |
| X output voltage             |                               |      |      |      |       |
| Low level                    | 600µA clock high              |      |      |      | V     |
| High level                   | I <sub>OH</sub> = 10µA        | 2.0  | 0.4  |      | V     |
| Input capacitance            | All inputs                    |      | 4.0  | 10   | pF    |
| Power supply current         |                               |      | 20   | 40   | mA    |
| <b>ac characteristics</b>    |                               |      |      |      |       |
| Clock frequency              |                               | 0.01 |      | 0.1  | MHz   |
| Chip enable access time      |                               |      |      | 250  | ns    |
| Switch characteristics       |                               |      |      |      |       |
| Contact resistance           | closed                        |      |      | 300  | Ω     |
|                              | open                          | 10   |      |      | MΩ    |

Figure 1 KR9600 - PRO Block diagram



## Operation

The keys are scanned in a nine output by ten input matrix, each key having a unique input-output combination connected to it. The inputs all go selectively to a level detector which has logically variable (1's and 0's) levels and hysteresis. The outputs are enabled one at a time from output X0 towards X8, at a rate of 10-100kHz, through a 9 stage counter. The 10 inputs are searched one at a time from Y0 to Y9, through a 10 stage ring counter, each time one of the outputs is enabled. The output and input pins all have pullups to V<sub>cc</sub> and are precharged each clock even if the scan is stopped at one key. When a level on the selected path to the comparator matches a level on the corresponding comparator input from the 10 stage ring counter and the key has not been encoded, the switch bounce delay network is enabled. The key down stroke is examined without advance to the next key location, until the key has been stable for the length of the DELAY CAP pin to discharge. The code for the depressed key is transferred to the output data buffer and the data ready signal appears.

The scan has two modes as determined by the LOckout/Rollover option. Once a key is determined to be down the scan will not advance if in the LOckout mode. Consequently a new key closure is not detected until the previously depressed key is released. The scan sequence will resume upon key release and the output data buffer stores the code of the last key encoded. In the Rollover mode a "1" is stored in the encoded key memory and the scan sequence is resumed and the code for the last encoded key remains in the data output buffer. Each depressed key is encoded regardless of the state of the previously depressed keys. The internal keyboard ROM is 10 bits wide. Bits 1-8 are output via outputs B1-B8.

## Description of pin functions

| Name             | Symbol          | Pin   | Function   |
|------------------|-----------------|-------|--|
| X outputs        | X0-X8           | 40-32 | External outputs from the 9-stage ring counter to the keyboard to form X-Y matrix with the keyboard switches as the crosspoints.                           |
| Y inputs         | Y0-Y9           | 17-26 | External inputs from the keyboard X-Y matrix   |
| Clock            |                 | CK    | 1-3 Oscillator connection pins   |
| Any key down     | AKO             | 5     | Output indicator of key closure  |
| Data outputs     | B9-B1           | 6-14  | Data outputs B1-B9 parallel outputs  |
| Data ready       | DR              | 16    | This output is a pulse which signals that a key closure has been detected and that data is available at the output port.                                   |
| Delay node input | Delay           | 31    | Externally controllable delay network for eliminating the effect of switch contact bounce.   |
| Shift input      | Shift           | 29    | This input is used to select the shift mode data   |
| Control input    | CNTRL           | 28    | This input is used to select the control mode data. Simultaneous assertion of shift and control inputs will place the encoder into the shift-control mode. |
| Lockout/rollover | LO/RO           | 4     | Selects the mode of operation for key scan   |
| Power supply     | V <sub>cc</sub> | 30    | +5V power supply   |
| Ground           | Gnd             | 15    | Ground   |

**Oscillator:**

The main clocks are derived from the Internal oscillator, three pins (pins #1,2,3) for frequency selection via an external resistor and capacitor are used.

**Lockout/Rollover: LO/RO**

This option selects the operation of the key scan when a new key is detected. In Lockout the scan stops as long as the key is down. In Rollover the scan stops till the new key is debounced by the DELAY CAP and the key code is output. Then the key position is marked as down and the scan continues until another new key is seen. The option is selected by an external pin. Lockout is active high and an on chip pulldown resistor is included.

**Data ready:**

The data ready pin gives a pulse upon an output state ready to transfer. This transfer occurs when a new key is encoded or when the current key is repeated.

**Any key down: AKO output**

The AKO output is an indicator to tell there is at least one key determined to be depressed. The output is logic high (true).

**Shift control: SC**

These two pins determine the output in response to a new key being detected. See coding sheet for specific outputs.

**Minimum switch closure**


$$T = \text{Switch bounce} + (90 \times 1/f) + \text{Strobe delay} + \text{Strobe width}$$

|                  |                                      |                                    |   |
|------------------|--------------------------------------|------------------------------------|---|
| maximum expected | determined by frequency of operation | determined by external capacitance | minimum time required by external circuitry |
|------------------|--------------------------------------|------------------------------------|---|

Figure 3 Timing diagram

**CONDITIONS:**

A key is pressed down at X0Y0 but the delay cap has not time out.  
Data Ready is high true and we have already had another key.  
DataRP = Data Ready as a Pulse.



The output of the 9600 PRO is a simple binary code which may be converted to a standard information code by a PROM or directly by a microprocessor. This permits a user maximum flexibility of key layout with simple field programming.

The code in the 9600 is shown in Table 1. The format is simple: output bits, 9,8,7,6,5,4 and 1 are a binary sequence. The count starts at X0, Y0 and increments through X0Y1, X0Y2...X8Y9; bit 9 is the LSB; bit 1 is the MSB.


Bit 2 and 3 indicate the mode as follows:

| Bit 2 | Bit 3 |               |
|-------|-------|---------------|
| 0     | 0     | Normal        |
| 0     | 1     | Shift         |
| 1     | 0     | Control       |
| 1     | 1     | Shift Control |

For maximum ease of use and flexibility, an internal scanning oscillator is used, with pin selection of N-key lockout (also known as 2-key rollover) and N-key rollover. An 'any-key-down' output is provided for such uses as repeat oscillator keying.

Figure 2 Oscillator and strobe selection graphs

## Oscillator frequency vs C1 for 9600



## Strobe delay vs C2 for 9600




Table 1 9600-Pro coding sheet

| XY | Normal<br>B-12345678910 | Shift<br>B-12345678910 | Control<br>B-12345678910 | Shift/Control<br>B-12345678910 |
|----|-------------------------|------------------------|--------------------------|--------------------------------|
| 00 | 000000000               | 001000000              | 010000000                | 011000000                      |
| 01 | 000000001               | 001000001              | 010000001                | 011000001                      |
| 02 | 000000010               | 001000010              | 010000010                | 011000010                      |
| 03 | 000000011               | 001000011              | 010000011                | 011000011                      |
| 04 | 000000100               | 001000100              | 010000100                | 011000100                      |
| 05 | 000000101               | 001000101              | 010000101                | 011000101                      |
| 06 | 000000110               | 001000110              | 010000110                | 011000110                      |
| 07 | 000000111               | 001000111              | 010000111                | 011000111                      |
| 08 | 000001000               | 001001000              | 010001000                | 011001000                      |
| 09 | 000001001               | 001001001              | 010001001                | 011001001                      |
| 10 | 000001010               | 001001010              | 010001010                | 011001010                      |
| 11 | 000001011               | 001001011              | 010001011                | 011001011                      |
| 12 | 000001100               | 001001100              | 010001100                | 011001100                      |
| 13 | 000001101               | 001001101              | 010001101                | 011001101                      |
| 14 | 000001110               | 001001110              | 010001110                | 011001110                      |
| 15 | 000001111               | 001001111              | 010001111                | 011001111                      |
| 16 | 000001000               | 001010000              | 010010000                | 011010000                      |
| 17 | 000001001               | 001010001              | 010010001                | 011010001                      |
| 18 | 0000010010              | 001010010              | 010010010                | 011010010                      |
| 19 | 0000010011              | 001010011              | 010010011                | 011010011                      |
| 20 | 0000010100              | 001010100              | 010010100                | 011010100                      |
| 21 | 0000010101              | 001010101              | 010010101                | 011010101                      |
| 22 | 0000010110              | 001010110              | 010010110                | 011010110                      |
| 23 | 0000010111              | 001010111              | 010010111                | 011010111                      |
| 24 | 0000011000              | 001011000              | 010011000                | 011011000                      |
| 25 | 0000011001              | 001011001              | 010011001                | 011011001                      |
| 26 | 0000011010              | 001011010              | 010011010                | 011011010                      |
| 27 | 0000011011              | 001011011              | 010011011                | 011011011                      |
| 28 | 0000011100              | 001011100              | 010011100                | 011011100                      |
| 29 | 0000011101              | 001011101              | 010011101                | 011011101                      |
| 30 | 0000011110              | 001011110              | 010011110                | 011011110                      |
| 31 | 0000011111              | 001011111              | 010010000                | 011000000                      |
| 32 | 0000100000              | 001100000              | 010100000                | 011100000                      |
| 33 | 0000100001              | 001100001              | 010100001                | 011100001                      |
| 34 | 0000100010              | 001100010              | 010100010                | 011100010                      |
| 35 | 0000100011              | 001100011              | 010100011                | 011100011                      |
| 36 | 00001000100             | 0011000100             | 0101000100               | 0111000100                     |
| 37 | 0000100101              | 0011000101             | 0101000101               | 0111000101                     |
| 38 | 0000100110              | 0011000110             | 0101000110               | 0111000110                     |
| 39 | 0000100111              | 0011000111             | 0101000111               | 0111000111                     |
| 40 | 0000101000              | 001101000              | 010101000                | 011101000                      |
| 41 | 0000101001              | 001101001              | 010101001                | 011101001                      |
| 42 | 0000101010              | 001101010              | 010101010                | 011101010                      |
| 43 | 0000101011              | 001101011              | 010101011                | 011101011                      |
| 44 | 0000101100              | 001101100              | 010101100                | 011101100                      |
| 45 | 0000101101              | 001101101              | 010101101                | 011101101                      |
| 46 | 0000101110              | 001101110              | 010101110                | 011101110                      |
| 47 | 0000101111              | 001101111              | 010101111                | 011101111                      |
| 48 | 0000110000              | 001110000              | 010110000                | 011110000                      |
| 49 | 0000110001              | 0011100001             | 010110001                | 011110001                      |
| 50 | 0000110010              | 0011100010             | 0101100010               | 0111100010                     |
| 51 | 0000110011              | 0011100011             | 0101100011               | 0111100011                     |
| 52 | 0000110100              | 0011100100             | 0101100100               | 0111100100                     |
| 53 | 0000110101              | 0011100101             | 0101100101               | 0111100101                     |
| 54 | 0000110110              | 0011100110             | 0101100110               | 0111100110                     |
| 55 | 0000110111              | 0011100111             | 0101100111               | 0111100111                     |
| 56 | 0000111000              | 0011100000             | 0101100000               | 0111100000                     |
| 57 | 0000111001              | 0011100001             | 0101100001               | 0111100001                     |
| 58 | 0000111010              | 0011100010             | 0101100010               | 0111100010                     |
| 59 | 0000111011              | 0011100011             | 0101100011               | 0111100011                     |
| 60 | 0000111100              | 0011100100             | 0101100100               | 0111100100                     |
| 61 | 0000111101              | 0011100101             | 0101100101               | 0111100101                     |
| 62 | 0000111110              | 0011100110             | 0101100110               | 0111100110                     |
| 63 | 0000111111              | 0011100111             | 0101100111               | 0111100111                     |
| 64 | 100000000               | 101000000              | 110000000                | 111000000                      |
| 65 | 1000000001              | 1010000001             | 1100000001               | 1110000001                     |
| 66 | 1000000010              | 1010000010             | 1100000010               | 1110000010                     |
| 67 | 1000000011              | 1010000011             | 1100000011               | 1110000011                     |
| 68 | 10000000100             | 10100000100            | 11000000100              | 11100000100                    |
| 69 | 10000000101             | 10100000101            | 11000000101              | 11100000101                    |
| 70 | 10000000110             | 10100000110            | 11000000110              | 11100000110                    |
| 71 | 10000000111             | 10100000111            | 11000000111              | 11100000111                    |
| 72 | 100000001000            | 101000001000           | 110000001000             | 111000001000                   |
| 73 | 100000001001            | 101000001001           | 110000001001             | 111000001001                   |
| 74 | 100000001010            | 101000001010           | 110000001010             | 111000001010                   |
| 75 | 100000001011            | 101000001011           | 110000001011             | 111000001011                   |
| 76 | 100000001100            | 101000001100           | 110000001100             | 111000001100                   |
| 77 | 100000001101            | 101000001101           | 110000001101             | 111000001101                   |
| 78 | 100000001110            | 101000001110           | 110000001110             | 111000001110                   |
| 79 | 100000001111            | 101000001111           | 110000001111             | 111000001111                   |
| 80 | 1000000010000           | 1010000010000          | 1100000010000            | 1110000010000                  |
| 81 | 1000000010001           | 1010000010001          | 1100000010001            | 1110000010001                  |
| 82 | 1000000010010           | 1010000010010          | 1100000010010            | 1110000010010                  |
| 83 | 1000000010011           | 1010000010011          | 1100000010011            | 1110000010011                  |
| 84 | 1000000010100           | 1010000010100          | 1100000010100            | 1110000010100                  |
| 85 | 1000000010101           | 1010000010101          | 1100000010101            | 1110000010101                  |
| 86 | 1000000010110           | 1010000010110          | 1100000010110            | 1110000010110                  |
| 87 | 1000000010111           | 1010000010111          | 1100000010111            | 1110000010111                  |
| 88 | 1000000011000           | 1010000011000          | 1100000011000            | 1110000011000                  |
| 89 | 1000000011001           | 1010000011001          | 1100000011001            | 1110000011001                  |

Internal Oscillator (Pins 1, 2, 3)

Lockout/Rollover (Pin 4)

Internal Resistor to GND

Lockout is Logic 1

Pulse Data Ready

Any Key Down (Pin 5) Positive Output

Internal Resistor to GND on Shift

and Control Pins

## Applications

Figure 4 shows a PROM-encoded 64 key, 4 mode application, using a  $256 \times 8$  PROM, and Figure 5 a full 90 key, 4 mode application utilising a  $512 \times 8$  PROM.

If N-key rollover operation is desired, it is recommended that a diode be inserted in series with each switch as shown. This prevents 'phantom' key closures from resulting if three or more keys are depressed simultaneously.

Figure 4 9600-PRO typical application 64 key, 4 mode





Figure 5 9600-PRO typical application 90 key, 4 mode



The information provided in RS technical literature is believed to be accurate and reliable; however, RS Components assumes no responsibility for inaccuracies or omissions, or for the use of this information, and all use of such information shall be entirely at the user's own risk. No responsibility is assumed by RS Components for any infringements of patents or other rights of third parties which may result from its use. Specifications shown in RS Components technical literature are subject to change without notice.